



<i>Part Number:</i> <u>12194</u>	<i>Revision:</i> <u>B</u>	<i>Effective Date:</i> <u>07/02/02</u>	<i>By:</i> <u>J. INGERSLEV</u>
<i>Document Type (indicate):</i>			
◦ Bill of Material	◦ Drawing (may be attached)	◦ Specification	
• Assembly Instructions	◦ Operating Procedure	◦ Other	

Over-Rider Assembly Installation Instructions

I. Parts Included in Kit:

12126	FRONT VERTICAL OVER-RIDER	EA	2.00
13037	REAR VERTICAL OVER-RIDER	EA	2.00
12194	OVER RIDER INSTRUCTIONS	EA	1.00

II. Tools Required:

- 5/8" socket
- 5/8" Wrench

III. Installation Instructions

1. Rear:
 - a. Remove the Quick-Jacks if mounted using 5/8" socket and wrench.
 - b. Attach the rear Over-riders using a 5/8" socket.
2. Front:
 - a. Remove the Quick-Jacks if mounted using 5/8" socket and wrench.
 - b. Install the Over-Riders using 5/8" socket and wrench.