



<i>Part Number:</i> <u>11262</u>	<i>Revision:</i> <u>B</u>	<i>Effective Date:</i> <u>07/03/02</u>	<i>By:</i> <u>J. INGERSLEV</u>
<i>Document Type (indicate):</i>			
<input type="radio"/> Bill of Material	<input type="radio"/> Drawing (may be attached)	<input type="radio"/> Specification	
<input checked="" type="radio"/> Assembly Instructions	<input type="radio"/> Operating Procedure	<input type="radio"/> Other	

External Battery Jack Installation Instructions

I. Parts Included in Kit:


11195	EXTERNAL BATTERY POSTS	PR	1.00
12265	POSITIVE REMOTE BATTERY TERMINAL	EA	1.00
12266	NEGATIVE REMOTE BATTERY TERMINAL	EA	1.00
11262	BATTERY POST INSTRUCTIONS	EA	1.00

II. Tools Required:

- 1 1/4" Hole Saw
- Ruler
- Marker
- 2 Gauge Battery Cable with Eyelet Ends (Positive and Negative)

III. Installation Instructions

Left Quick Jack Bolts



1. Above is the placement for the Battery Post holes. Mark these and drill with the 1 1/4" hole saw.
2. Install the battery jacks onto the body.
3. Connect cables to the posts and to the battery.