



Factory Five Racing, Inc.

| | | | |
|--------------------|-------------|-------------------------|------------------|
| Part Number: 15637 | Revision: A | Effective Date: 3/13/14 | By: J. INGERSLEV |
|--------------------|-------------|-------------------------|------------------|

Center Dash support

INSTALLATION INSTRUCTIONS



$\frac{3}{8}$ " socket, $\frac{1}{8}$ " hex key, $\frac{3}{16}$ " drill bit, drill, rivet tool, tape measure marker


The Center dash support can be installed either under the carpet in which case the carpet will need to get slotted or, on top of the carpet.

| REV. | DESCRIPTION | DATE | APPROVED |
|------|-------------|------|----------|
| | | | |
| | | | |

DETAIL A
SCALE 1 : 3

| | | |
|--|---|--|
| <p>ROADSTER</p> <p>UNLESS OTHERWISE SPECIFIED:</p> <p>DIMENSIONS ARE IN INCHES</p> <p>TOLERANCES:</p> <p>TWO PLACE DECIMAL ±0.01</p> <p>THREE PLACE DECIMAL ±0.005</p> <p>FOUR PLACE DECIMAL ±0.001</p> <p>MATERIAL:</p> <p>FINISH:</p> <p>USED ON:</p> <p>APPLICATION:</p> | <p>NAME: Ji</p> <p>DATE: 2010</p> <p>DRAWN:</p> <p>COMMENTS:</p> <p>ISSUED: 3/13/2014</p> | <p style="text-align: center;">Factory Five Racing, Inc.</p> <p style="text-align: center;">TITLE: ROADSTER KIT</p> <p>SIZE: A DWG. NO.: 15626 REV: A</p> <p>SCALE: 1:25 WEIGHT: SHEET 2 OF 2</p> |
|--|---|--|

PROPRIETARY AND CONFIDENTIAL
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF FACTORY FIVE RACING, INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF FACTORY FIVE RACING, INC. IS PROHIBITED.



On top of the transmission tunnel measure back from the front of the tunnel 5.75" on each side and mark the tunnel top.



Hold the dash support so that the flat area in front of the holes is aligned with the marks made.



Mark the right front hole location on the tunnel.



Remove the support and drill a $\frac{3}{16}$ " rivet mounting hole at the point marked.



Remount the dash support and insert a rivet into the hole but do not pull the rivet.



Realign the left side of the support with the line and drill one of the rivet holes.



Rivet the bracket in the hole just made then pull the other rivet.

Drill and rivet the remaining two holes.

